

## LEVERLESS TIRE CHANGERS

- The latest in ease of use and wheel protection
- All the work of mounting & demounting is done by the machine - no tire lever required
- Wheel is clamped in the center - no more worries about scratching wheels with rim clamp jaws

### HOFMANN®

#### UNIVERSAL-2

- Center clamping / Leverless style
- For 12"-30" wheels, 17" max width, 47" max diameter
- Assist arm(s) to keep tire bead in the drop center of the wheel
- Integral wheel lift
- Adjustable work height of wheel
- Dual position bead breaker breaks both beads at the same time
- 2 speeds, with foot pedal & joystick control
- Electric (110V) power



### COATS®

#### PROGUARD

- Center clamping / Leverless style
- For 10"-34" wheels, 16" max width, 47" max diameter
- Assist arm(s) to keep tire bead in the drop center of the wheel
- Integral wheel lift
- Tilt back tower
- 2 speeds, with foot pedal control
- Electric (220V) power



### CORCHI

#### AM50

- Center clamping / Leverless style
- For 12"-30" wheels, 15" max width, 47" max diameter
- Assist arm(s) to keep tire bead in the drop center of the wheel
- Integral wheel lift
- 2 speeds, with foot pedal control
- Electric (110V) power



### Ranger PRODUCTS

#### RX3040

- Center clamping / Leverless style
- For 10"-30" wheels, 22" max width, 44" max diameter
- Assist arm(s) to keep tire bead in the drop center of the wheel
- Integral wheel lift
- Camera & monitor for underside viewing
- Footpedal & joystick control
- Electric (220V) power

### COATS®

#### APX80

- Outside clamping 9"-30" wheels
- Inside clamping 11"-32" wheels
- 16" max width, 44" max diameter
- 2 assist arms
- Tilt tower
- Electric (110V) or air power
- Pneumatic bead head
- Also available - APX90 (A or E)  
Adds an extra assist arm and an integral wheel lift
- Plastic protection parts available to prevent wheel damage



### HOFMANN®

#### 3550EM

- Outside clamping 12"-30" wheels
- Inside clamping 14"-28" wheels
- 17" max width, 47" max diameter
- 3 pc EasyMontPro assist arm
- Tilt tower
- Electric (110V) power
- Pneumatic bead head
- Available without assist arm as 3550  
- Outside clamping to 26" on 3550 (upgradable to 30" outside)
- Plastic protection parts available to prevent wheel damage





## 1625EM

- Outside clamping 10"-24" wheels
- Inside clamping 12"-26" wheels
- 15" max width, 42" max diameter
- 3 pc EasyMontPro assist arm
- Swing arm tower
- Electric (110V) power
- **Available without assist arm as 1625 Max diameter 50" for 1625**
- Extension clamp set available to allow outside clamping to 28"
- Plastic protection parts available to prevent wheel damage



## A2024TI-20

- Outside clamping 10"-24" wheels
- Inside clamping 13"-26" wheels
- 15" max width, 43" max diameter
- 1 assist arm
- Tilt tower
- Electric (110V) or air power
- **Available without assist arm as A2024TI**
- **Available with additional assist arm as A2024TI-2015**
- Extension clamp set available to allow outside clamping to 26"
- Plastic protection parts available to prevent wheel damage



## 70X (OLD 7060/7065)

- Outside clamping 6"-22" wheels
- Inside clamping 8"-24" wheels
- 14" max width, 50" max diameter
- 1 assist arm
- Swing arm tower
- Electric (110V) or air power
- Foot pedal or hand controlled bead breaker
- **3 accessory kits available:**

### Basic

**Extended** - Adds Gripmax clamping & additional protection items

**Premium** - Extended kit plus storage cabinet & duckhead for high offset wheels

- Extension clamp set available to allow outside clamping to 28"
- Plastic protection parts available to prevent wheel damage



## 50X (OLD 5060/5065)

- Outside clamping 6"-22" wheels
- Inside clamping 8"-24" wheels
- 14" max width, 50" max diameter
- Swing Arm Tower
- Electric (110V) or air power
- Foot pedal or hand controlled bead breaker
- **3 accessory kits available:**
- **Basic**
- **Extended** - Adds Gripmax clamping & additional protection items
- **Premium** - Extended kit plus storage cabinet & duckhead for high offset wheels
- Extension clamp set available to allow outside clamping to 28"
- Plastic protection parts available to prevent wheel damage
- **Upgradeable to 70x series with the addition of assist arm**



## A9824TI-1500

- Outside clamping 10"-24" wheels
- Inside clamping 13"-26" wheels
- 14" max width, 47" max diameter
- 1 assist arm
- Swing arm tower
- Electric (110V) or air power
- **Available without assist arm as A9824TI**
- Extension clamp set available to allow outside clamping to 28"
- Plastic protection parts available to prevent wheel damage



## 1565

- Outside clamping 10"-21" wheels
- Inside clamping 12"-24" wheels
- 13" max width, 40" max diameter
- Swing arm tower
- Electric (110V) power
- Extension clamp set available to allow outside clamping to 25"
- Plastic protection parts available to prevent wheel damage
- **Can be upgraded with the addition of the EasyMontPro assist arm**



## COATS®

### 5040

- Outside clamping 10"-21" wheels
- Inside clamping 12"-24" wheels
- 10 1/2" max width, 50" max diameter
- Swing arm tower
- Electric (110V) or air power
- Plastic protection parts available to prevent wheel damage
- Electric model available with tower storage as **5045E**



### TIRE CHANGER MOUNT / DEMOUNT HEADS

Stainless Steel

Model	OEM	OE Model	Application
<b>182788</b>	Coats	8182788	Most 5xxx, 6xxx, 7xxx series machines (tapered hole)
<b>183429</b>	Coats	8183429	RC1, 5, 10, 15, 20, early 5060 (round hole)
	Corgi	258458	All models
<b>ST4026251</b>	Hofmann	ST4026251	1520, 1565, 1620, 1625, 3300, 3550

Nylon

Model	OEM	OE Model	Application
<b>183061</b>	Coats	8183061	Most 5xxx, 6xxx, 7xxx series machines (tapered hole)
<b>ST24335 *</b>	Accuturn	20024335	3602, 4260, 4560, 4602, 5602
	Hofmann	24335	1520, 1565, 1620, 1625, 3300, 3550
	John Bean	24335	System IIE, III, IV, IVE
	Snap On	24335	All models
<b>3008403 **</b>	Coats	83008403	RC1, 5, 10, 15, 20, early 5060, 9010, 9024, APX90
	Corgi	450310	All rim clamp
	Hofmann	8314813	All early models except 1550, 1620, 1625
	Hunter	RP11-8314813	TCX series
<b>RP6-0343</b>	Accuturn	SM102529	220A (all other models require 102765 adapter)
	Hunter	RP6-0343B	TC250, TC300, TC325
<b>184432</b>	Coats	8184432	Most 5xxx, 6xxx, 7xxx series machines (tapered hole) - For high offset wheels

\* If there has never been a nylon duckhead installed on the machine, use kit EAA0247G20A, which has the required adapter.

\*\* If there has never been a nylon duckhead installed on the machine, use kit 2008402, which has the required adapter.

Early Coats rim clamp machines (w/round hole duckheads) can be converted to use standard duckheads with the addition of a shaft conversion kit.

### CENTER POST CHANGER ACCESSORIES

#### 70200 COMBOTOOL

- Works with all center post tire changers, replaceable plastic inserts protect wheels from damage
- Replacement inserts for 70200:  
**70202** - Nose insert  
**70204** - Hook insert



#### 106572 LUBE BUCKET

- Angled neck lube bucket, Coats center post machines



## CORGHI

### A9220TI

- Outside clamping 10"-20" wheels
- Inside clamping 13"-23" wheels
- 12.5" max width, 42" max diameter
- Tilt tower
- Electric (110V) or air power
- **Available with assist arm as A9220TI-1500**
- Extension clamp set available to allow outside clamping to 24"
- Plastic protection parts available to prevent wheel damage



## HOFMANN®

### 2700

- Center post machine
- Wheel diameter - 10-18"
- 20" max width, 40" max diameter
- Air power
- Dual power cylinders
- Dual bead breaker - breaks both beads at the same time
- Plastic protection parts available



## COATS®

### 4050A

- Center post machine
- Wheel diameter - 10-18"
- 10 1/2" max width, 38" max diameter
- Upgradeable to 19" width
- Air power
- Plastic protection parts available



## 181354-1 BEAD LIFTING TOOL

- Forged steel, plated for corrosion protection



## 5000783 LIFT TOOL SOCK

- For use with 181354-1 lift tool, pack of 10 (s/s from 183605)



## 182963 PLASTIC INSERTS

- For 182788 mount / demount head, pack of 12



## 183604 CLAMP SOCK

- Slip on jaw covers for Coats rim clamp machines (except 9010 & Gripmax clamp sets) 10 pk



## 183606 BEAD LOOSENER SOCK

- For use on all Coats rim clamp machines - 2 pk



## 181855 BEAD BREAKER PAD

- Rubber bead breaker pad, center, for Coats 5xxx (except 5030), 6xxx and 7xxx series rim clamp tire changers



## 181851 BEAD BREAKER PAD

- Nylon bead breaker pad, top or bottom, for Coats 5xxx (except 5030), 6xxx and 7xxx series rim clamp tire changers



## 70210 DROP CENTERTIRE CLAMP

- For use with rim clamp tire changers - clamps to the rim to help hold the bead in wheel drop center
- Plastic material - will not scratch aluminum wheels
- Steel version available as **70215**



## 14-378 TIRE SWAB

- Cotton, 11 1/2" long, for use with liquid lube



## 14-378L TIRE SWAB, LONG

- Cotton, 14 1/2" long, for use with liquid lube



## 106259 LUBE BUCKET

- Straight neck lube bucket, for Coats rim clamp machines



## COATS RIM CLAMP "X" SERIES CLAMP SETS

### 184926 STANDARD CLAMP SET

- Inside / outside clamping (6"-22" outside), 3 position



### 184327 EXTENDED CLAMP SET

- Outside clamping only - for 13"-24" wheels, 2 position, includes 183604 clamp sock set

### 184958 EXTENDED CLAMP SET

- Outside clamping only - for 16"-28" wheels, 2 position



### 5000758 GRIPMAX CLAMP SET

- Wheel protection integrated into the clamp - no covers required
- Inside / outside clamping (6"-22" outside)
- Also for use on the APX series (9"-30" outside)
- **500059408**: Replacement plastic grip set (8)
- **5000768**: Rebuild set w/8 plastic grips, 8 metal grips & assembly hardware



### 5606361 GRIPMAX EXTENDED CLAMP SET

- Outside clamping only - for 16"-28" wheels
- All Gripmax clamps use the same replacement parts

## EXTENDED CLAMP SETS & ATV CLAMP SETS AVAILABLE FOR MOST MACHINES CALL FOR DETAILS

## PASTE MOUNTING LUBE

- Wax style paste, 7-3/4 lb bucket
- 75**: Standard profile bucket
- 75N**: Low profile bucket



## 73 PASTE LUBE BRUSH

- 45° 1" brush head (use with #75 paste)

